

American BackCountry Heat Seals



CAUTION! Heat Seals Will Melt if Placed Under Heat Press Platen

The American BackCountry Collection by Vapor Apparel are tagless garments, which have a heat seal in the nape of the neck. If placed under direct heat, the heat seal will melt.

Below are ways to easily press the garment while avoiding direct heat on the seal area.



How to Press the American BackCountry Line with Heat Seal



Using the Vapor Foam Kit, cut a small square of foam to cover the entire heat seal area, tucking the foam under the ribbed collar. Only use foam from the Vapor Foam Kit as it has been treated to handle the high heat temperatures needed for sublimation. Replace foam when worn or flattened from platen pressure. This method allows for the most flexibility with graphic placement.



Before pressing shirt, make sure the entire heat seal is hanging off the press so that the top platen does not make contact when lowered.



Sling the shirt over the bottom press plate before lowering top platen.

